



NEEDED FOR MOUNTING



PANEL DIMENSIONS (mm)



WARNING

- Turn power off before inspection, installation or removal.
- Properly ground electrical enclosure.
- Luminaire may fall down if not installed properly.
- Avoid direct eye exposure to the light source while it is on.
- For indoor use only.
- Dry location only.
- Do not operate luminaire with damaged parts.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- The manufacturer shall not be liable for any damage resulting from inappropriate modifications to the luminaire or faulty installation.

If you have any questions, contact the manufacturer.








5 YEARS WARRANTY

KAGULUX HE BACKLIT PANEL INSTALLATION GUIDE

IP20

RECESSED MOUNTING

RoHS Compliant



5 YEARS WARRANTY


IP20

RoHS Compliant



KAGULUX HE BACKLIT PANEL INSTALLATION GUIDE

RECESSED MOUNTING



CONNECTION DIAGRAM

STANDARD



DALI

