



## NEEDED FOR MOUNTING



## PANEL DIMENSIONS (mm)



## WARNING

- Turn power off before inspection, installation or removal.
- Properly ground electrical enclosure.
- Luminaire may fall down if not installed properly.
- Avoid direct eye exposure to the light source while it is on.
- For indoor use only.
- Dry location only.
- Do not operate luminaire with damaged parts.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- The manufacturer shall not be liable for any damage resulting from inappropriate modifications to the luminaire or faulty installation.

*If you have any questions, contact the manufacturer.*


5 YEARS WARRANTY

# KAGULUX HE BACKLIT PANEL INSTALLATION GUIDE


IP20

## RECESSED MOUNTING


RoHS Compliant




1




2



3




4




5



6



7



8

5 YEARS WARRANTY

IP20

RoHS Compliant


CE

RoHS Compliant

F

# KAGULUX HE BACKLIT PANEL INSTALLATION GUIDE

## RECESSED MOUNTING



## CONNECTION DIAGRAM

### STANDARD



### DALI

